

ASSEMBLY INSTRUCTIONS


MODEL NO. RCN3222STG




Assembly HARDWARE				
S/N	PICTURE	NAME	TOTAL QTY	REMARK
A		CAM SCREW	18+1(SPARE)	
B		KLIX CAM	18+1(SPARE)	
C		CAM COVER STICKER	18+1(SPARE)	use cam covers to cover any klix cam screws
D		WOOD DOWEL	12+1(SPARE)	
E		LEVELER	4PCS	
F		SHELF PEG	4+1(SPARE)	
G		HINGE	4PCS	
H		LOCK	1SET	
I		LATCH	1SET	
J		Handle With Screws	2SET	

PART LIST


① TOP PANEL
② LEFT SIDE PANEL
③ RIGHT SIDE PANEL
④ BASE PANEL
⑤ BACK SUPPORT
⑥ BASE SUPPORT
⑦ SHELF
⑧ DOOR(2)



1. INSTALL THE "E" LEVELERS ON THE BOTTOM OF BASE SUPPORT ⑥.
E(4x)



2. INSTALL "A" CAM SCREWS AND "D" DOWELS INTO SIDE PANEL ③ AND "B" KLIX CAMS INTO BACK PANEL ⑤ . CONNECT PANEL ③ TO ⑤ . TIGHTEN. REPEAT STEP TO CONNECT ②TO ⑤.
A (6x)
B (6X)
D(4X)



IMPORTANT:


FUNCTION OF KLIX CAM




1/4 RIGHT TURN FOR LOCKING

MAKE SURE THE ARROW IS POINTING TO THE OPEN HOLE BEFORE INSERTING INTO THE PANELS HOLE


3. INSTALL "A" CAM SCREWS AND "D" DOWELS ON UNDERSIDE OF TOP ① & BOTTOM PANEL ④ .
   A(12x)
   D(8X)



4. INSTALL "B" KLIX CAMS INTO SIDE PANELS ② ③ & ⑤. THEN CONNECT BOTTOM PANEL ④ TO ② ③ & ⑤. TIGHTEN. REPEAT STEP TO CONNECT TOP PANEL ① TO ② ③ & ⑤ .
   B(12x)





5. INSERT "F" SHELF PEGS INTO SIDE PANELS ② AND ③ . SET SHELF ⑦ ON TOP OF PEGS.
F(4X)




6. INSTALL "G" HINGES ON INSIDE OF DOOR ⑧, 2 PER DOOR. ATTACH HINGE TO INSIDE OF SIDE PANELS ② AND ③, ADJUST AS NEEDED. SEE BOX.
G(4X)

To adjust doors







7. INSTALL "J" HANDLES ON DOOR ⑧. ONE PER DOOR.
J(2x)




8. INSTALL "I" LATCH ON THE UNDERSIDE OF TOP ① AND ON INSIDE OF LEFT FACING DOOR ⑧.(DOOR ATTACHED TO PANEL②)
I (1x)




9. INSTALL "H" LOCK UNDER TOP ① & ON INSIDE OF RIGHT FACING DOOR ⑧.(DOOR ATTACHED TO PANEL③)
H(1X)




10. USE "C" CAM COVERS STICKERS TO COVER ALL EXPOSED KLIX CAMS.
C (18x)



11. COMPLETED





32*22*29.5"
W800*D560*H750mm